

QUICK START GUIDE

Non-contact Infrared Thermometer

1. Product Structure

1.Probe

2.LCD Display

3.Memory Button/Adjustable Button

4.Memory Button/Adjustable Button

5.Mode Button (Body/Surface)

6.Measure Button

7.Battery Cover

2. Display Description

1.Surface temperature

2.Body temperature

3.Display Value

4.Storage Location

5.Battery Symbol

6.Buzz Symbol

7.Temperature Unit

8.Storage Data Readout

3. How to Set Temperature Unit & Mute/Unmute Mode?

Press the “Mode” button to enter the F1 mode. Under the F1 mode you can press the +/- button to switch between °F/°C. Then continue to press the set button 4 times to exit and save the setting.

Press the “Mode” button to enter the F4 mode. Under the F4 mode, you can press the +/- button to turn on/off the beep sound. Then continue to press the set button 1 time to exit and save the setting. In the mute mode, the 🔇 will not display on the screen.

Under F1 Function

Press the +/- button to switch between °F/°C

Under F4 Function

Press the +/- button to turn on/off the beep sound

4. How To Read History Readings?

- 1.Keep the thermometer turned on.**
- 2.Press Memory Button to get into the memory mode.**
- 3.Press the +/- button again to check the 32 sets of memories one by one.**

Press Memory Button

Page 2

5. Notice

- 1.Continuous measurement will heat up the sensor, which will make the readings inaccurate. To get the accurate temperature, please wait about 10 seconds between each measurement.**
- 2.Keep a distance of 3–5 cm (1.2–2 inches) when measure forehead temperature.**
- 3.Take the forehead temperature in the correct place: The center of forehead.**

Far away from forehead

Distance of 3–5 cm (1.2–2 inches)

6. Measure Forehead Temperature

1.Press the measure button to turn on the machine.

Power on

2.Press the mode button to choose body mode.

Choose mode

3.Point the probe at the center of forehead, with a distance of 3–5 cm (1.2–2 inches).

4.Press the button and get the temperature.

Measure

7. Measure Surface Temperature

1.Press the measure button to turn on the machine.

Power on

2.Press the mode button to choose surface mode.

Choose mode

3.Point the probe at the center of surface, with a distance of 3–5 cm (1.2–2 inches).

4.Press the button and get the temperature.

Measure

TEKS SASARAN

Halaman 1

PANDUAN PENGGUNAAN PANTAS

Termometer Inframerah Tanpa Sentuh

1. Struktur Produk

- 1. Kuar**
- 2. Paparan LCD**
- 3. Butang Memori/Butang Boleh Laras**
- 4. Butang Memori/Butang Boleh Laras**
- 5. Butang Mod (Badan/Permukaan)**
- 6. Butang Ukur**
- 7. Penutup Bateri**

2. Penerangan Paparan

- 1. Suhu permukaan**
- 2. Suhu badan**
- 3. Nilai Paparan**
- 4. Lokasi Penyimpanan**
- 5. Simbol Bateri**
- 6. Simbol Buzz**
- 7. Unit Suhu**

8. Bacaan Data Storan

3. Bagaimana untuk Menetapkan Unit Suhu & Mod Senyap/Mod Nyahsenyap?

Tekan butang "Mode" untuk memasuki mod F1. Dalam mod F1 anda boleh menekan butang +/- untuk bertukar antara °F/°C. Kemudian terus menekan butang set 4 kali untuk keluar dan simpan tetapan.

Tekan butang "Mode" untuk memasuki mod F4. Dalam mod F4, anda boleh menekan butang +/- untuk menghidupkan/mematikan bunyi bip. Kemudian terus menekan butang set 1 kali untuk keluar dan simpan tetapan. Dalam mod senyap, simbol  tidak akan dipaparkan pada skrin.

Dalam Fungsi F1

Tekan butang +/- untuk beralih antara °F/°C

Dalam Fungsi F4

Tekan butang +/- untuk menghidupkan/mematikan bunyi bip

4. Bagaimana untuk Membaca Bacaan Dahulu?

- 1. Pastikan termometer dihidupkan.**
- 2. Tekan Butang Memori untuk masuk ke mod memori.**
- 3. Tekan butang +/- sekali lagi untuk menyemak 32 rekod bacaan satu demi satu.**

Tekan Butang Memori

5. Notis

- 1. Pengukuran yang berterusan akan memanaskan penderia, yang mana akan menjadikan bacaan tidak tepat. Untuk mendapatkan suhu yang tepat, sila tunggu kira-kira 10 saat antara setiap pengukuran.**
- 2. Kekalkan jarak 3–5 cm (1.2–2 inci) apabila mengukur suhu dahi.**
- 3. Ambil suhu dahi di tempat yang betul: Pusat dahi.**

Jauh dari dahi.

Jarak 3–5 cm (1.2–2 inci)

6. Ukur Suhu Dahi

- 1. Tekan butang ukur untuk menghidupkan mesin.**

Hidupkan

- 2. Tekan butang "Mode" untuk memasuki mod F1.**

Pilih mod

- 3. Halakan kuar pada bahagian tengah dahi, dengan jarak 3–5 cm (1.2–2 inci).**
- 4. Tekan butang dan dapatkan suhu.**

Ukur

7. Ukur Suhu Permukaan

- 1. Tekan tombol ukur untuk menghidupkan mesin.**

Hidupkan

- 2. Tekan tombol Mode untuk memasuki mod F1.**

Pilih mod

- 3. Halakan kuar pada bahagian tengah dahi, dengan jarak 3–5 cm (1.2–2 inci).**
- 4. Tekan tombol dan dapatkan suhu.**

Ukur